

# Nanomaterials for Advanced Life Support in Space systems

Rama kumar Allada, Ph.D.  
NASA Johnson Space Center  
Houston, TX  
*[Ram.allada-1@nasa.gov](mailto:Ram.allada-1@nasa.gov)*

# Topic Outline

---

- Introduction
  - Nanomaterials research at NASA JSC
  - Focus on carbon nanotubes
- Research and accomplishments in CO<sub>2</sub> removal
  - Current Technology
  - Goals
  - Results
- Research and accomplishments in water purification
  - Current Technology
  - Goals
  - Results
- Next Steps

# Nanomaterials: Fundamentals to Applications

## Growth/Production

Laser and HiPco  
Production and  
Diagnostics

## Characterization


Purity, Dispersion, Consistency, Type  
SWCNT Load Transfer  
Single Fiber Diffusivity

## Processing


Purification  
Functionalization  
Dispersion  
Alignment

## Collaboration

Academia, Industry, Government




Single Fiber Thermal Diffusivity



Fuel Cells



Ultracapacitors (SAFER)




Nanofiltration

## Applications For Human Spaceflight

| APPLICATION | PARTNERS | TRL |   |   |   |   |
|-------------|----------|-----|---|---|---|---|
|             |          | 1   | 2 | 3 | 4 | 5 |

|  |                              |   |   |   |   |   |
|--|------------------------------|---|---|---|---|---|
| Ultracapacitors  | EP, Glenn, Industry          | X | X | X | X | X |
| Proton Exchange Membrane – PEM - Fuel Cells                          | EP, Glenn, Industry          | X | X |   |   |   |
| RCRS - Regenerable CO <sub>2</sub> Removal System                    | EC, Ames, Industry           | X | X |   |   |   |
| Active / Passive Thermal Management Materials                        | EC, Rice, ORNL, Industry     | X | X |   |   |   |
| Nanofiltration for Water Recovery                                    | EC, Industry                 | X | X |   |   |   |
| Electromagnetic Shielding Materials (ESD/EMI)                        | EV, Rice, LaRC, Industry     | X | X | X | X |   |
| Advanced Nanostructured Materials for Thermal Protection and Control | ES3, Ames, Goddard, Industry | X | X |   |   |   |
| Radiation Dosimeter  | NX, Rice, PV, LaRC, Ames     | X |   |   |   |   |
| Nanotube-Based Structural Composites                                 | ES, Rice, UH, LaRC           | X | X |   |   |   |



Ceramic Nanofibers (TPS)



High Thermal Conductivity Fabrics



CO<sub>2</sub> Removal




Electromagnetic Shielding

# Nanomaterials: Single Wall Carbon Nanotubes

## Unique Properties


- Exceptional strength
- Interesting electrical properties (metallic, semi-conducting, semi-metal)
- High thermal conductivity
- Large aspect ratios
- Large surface areas



Single Wall Carbon Nanotube

## Size Comparison -

$C_{60}$ , Nanotubes, and Atoms



## Possible Applications

- High-strength, light-weight fibers and composites
- Nano-electronics, sensors, and field emission displays
- Radiation shielding and monitoring
- Fuel cells, energy storage, capacitors
- Biotechnology
- Advanced life support materials
- Electromagnetic shielding and electrostatic discharge materials
- Multifunctional materials
- Thermal management materials

## Current Limitations

- High cost for bulk production
- Inability to produce high quality, pure, type specific SWCNTs
- Variations in material from batch to batch
- Growth mechanisms not thoroughly understood
- Characterization tools, techniques and protocols not well developed

# **Air Revitalization using Carbon Nanotubes**

---




- CNTs have useful properties that make them suitable for use in regenerable adsorbent technologies
  - High surface area and porosity – more adsorbent in less volume
  - Thermal conductivity – useful for thermal regeneration of packed beds
  - Chemical inertness along with potential functionality – the support phase can be bonded to scrubbing polymers such as amines

# Initial Results and Technology Assessment

---

## 2004 Results

- Carbon Nanotubes have high surface area: bucky pearls, fibers, bucky paper
- TGA experiment: the amine is reactive with the CO<sub>2</sub> gas stream
- Poor adherence to nanotube surface - requires a specific pore size and shape
- We need a better way to integrate the support phase with the amine






# Functionalization of SWCNTs with Amines

---

- Since amines are volatile the coating would be prone to degradation during repeated thermal or vacuum driven renewal of the adsorbent.
- Chemically bonding of the amine to the support phase was a solution to this problem



# CO<sub>2</sub> Uptake Measurements

---





Experimental conditions

- Flow rate 500 cc/min – 1% CO<sub>2</sub> (balance N<sub>2</sub>)
- Regeneration: Low vacuum (off-line) for 1 hour





# Results: Functionalization

---



FTIR and Raman spectroscopy data provide evidence of surface modification of the SWCNT, which indicates that carboxylic acid groups are bonded to the carbon nanotubes.


# Results: Thermal Decomposition and XPS



XPS analysis of the nitrogen peak serves to monitor removal of amines (nitrogen) as a function of temperature via changes in peak height

Comparison of TGA curves for functionalized and coated SWCNT indicates that the amine remains attached to SWCNT well above the TSA temperature range

# Results: Comparison with current technologies



High equilibrium capacity


Lower regeneration capacity – poor vacuum results in incomplete desorption

## Next Steps


---

- Investigate derivatizing SWCNTs with NASA approved amine formulation
- Testing and determining CO<sub>2</sub> uptake capacity; both maximum and cyclic
  - Thermal swing
  - Vacuum swing
- Plans for scale-up
- Integration into flight hardware

# Nanostructured Water Disinfection Device






- Efficient disinfection
  - Low power
  - No consumables
- Collaboration between Crew & Thermal Systems and Structural Engineering Divisions of NASA JSC





# Ultra Violet Test Stand

Bring all those pieces together and .....




# Fullerene Coated slides

---


- Fullerene can be dissolved from a bulk material (colloids) into single fullerene particles (Bucky balls) with certain solvents.
  - Toluene
  - Carbon Disulfide
  - Benzene
- Slide preparation
  - Etched
  - Hydrofluoric (HF) Acid
  - Etched and HF
  - Surface Application



# Singlet oxygen generation



# Year 1 results: Bacterial efficacy



## Next Steps

---

- Investigating substrate preparation methods by vapor deposition
- Testing
  - bacterial degradation
  - coating longevity
- Scale-up to bench top device



# Acknowledgements

---

- Nanomaterials Project at JSC – Dr. Leonard L. Yowell (Advisor)
- Collaborators
  - Crew and Thermal Systems Division
  - Rice University
- Funding
  - This work was supported by the National Research Council and Oak Ridge Associated University postdoctoral programs at NASA
  - Andrew Welch Foundation (to W.E. Billups)
  - Center Director Discretionary Funding at NASA-JSC